



| Model                           | Description  | Partnr.                    |                                     |  |
|---------------------------------|--|----------------------------|-------------------------------------|--|
| <b>TOP ACE 3000</b>             |  |                            |                                     |  |
|                                 | Ribbon roll  | BLACK                      | ER 131491                           |  |
| <b>NEW ACE 3800</b>             |  |                            |                                     |  |
|                                 | Ribbon roll  | BLACK                      | ER 320490                           |  |
| <b>BX1500/BX1600</b>            |  |                            |                                     |  |
|                                 | Ribbon   | BLACK                      | CE 319252                           |  |
| <b>BX6000</b>                   |  |                            |                                     |  |
|                                 | Ribbon   | BLACK                      | CE 315153                           |  |
| <b>BX6200/BX6400</b>            |  |                            |                                     |  |
|                                 | Two Color Ribbon                                     | BLACK / RED                | CE 315252                           |  |
| <b>CP3000 / CP3200 / CP3300</b> |  |                            |                                     |  |
|                                 | Two Color Ribbon<br>High quality                     | BLACK / RED                | CE 316453                           |  |
| <b>DX3200 (DX3100)</b>          |  |                            |                                     |  |
|                                 | Two Color Ribbon                                     | BLACK / RED                | MR 352350                           |  |
| <b>DX7000</b>                   |  |                            |                                     |  |
|                                 | Ribbon   | BLACK                      | C 872304                            |  |
| <b>DX7200</b>                   |  |                            |                                     |  |
|                                 | Two Color Ribbon                                     | BLACK / RED                | C 872404                            |  |
| <b>EX3000N</b>                  |  |                            |                                     |  |
|                                 | Ribbon   | BLACK                      | CE 315153                           |  |
| <b>EX3200N/EX3500</b>           |  |                            |                                     |  |
|                                 | Two Color Ribbon<br>Two Color Ribbon<br>High quality | BLACK / RED<br>BLACK / RED | CE 315252<br>CE 316453              |  |
| <b>EX5000/EX5000N</b>           |  |                            |                                     |  |
|                                 | Ribbon   | BLACK                      | CE 315153                           |  |
| <b>EX5200N/EX5400N</b>          |  |                            |                                     |  |
|                                 | Two Color Ribbon                                     | BLACK / RED                | CE 315252                           |  |
| <b>EX60i</b>                    |  |                            |                                     |  |
|                                 | Ribbon   | BLACK                      | CE 315153                           |  |
| <b>EX6000N</b>                  |  |                            |                                     |  |
|                                 | Ribbon   | BLACK                      | CE 315153                           |  |
| <b>EX6200N/EX6400N</b>          |  |                            |                                     |  |
|                                 | Two Color Ribbon                                     | BLACK / RED                | CE 315252                           |  |
| <b>EX7000 / EX7500</b>          |  |                            |                                     |  |
|                                 | Ribbon   | BLACK                      | C 268056                            |  |
| <b>EX7600</b>                   |  |                            |                                     |  |
|                                 | Two Color Ribbon                                     | BLACK / RED                | C 267656                            |  |
| <b>MJR8000</b>                  |  |                            |                                     |  |
|                                 | Ribbon<br>Two Color Ribbon                           | BLACK<br>BLACK / RED       | C 872304<br>C 872404                |  |
| <b>MJR8500</b>                  |  |                            |                                     |  |
|                                 | Ribbon   | BLACK                      | CE 315153                           |  |
| <b>MR7000</b>                   |  |                            |                                     |  |
|                                 | Ribbon<br>Two Color Ribbon                           | BLACK<br>BLACK / RED       | C 872304<br>C 872404                |  |
| <b>MR9000</b>                   |  |                            |                                     |  |
|                                 | Ribbon<br>Two Color Ribbon                           | BLACK<br>BLACK / RED       | C 268056<br>C 267656                |  |
| <b>MRX30</b>                    |  |                            |                                     |  |
|                                 | Ribbon   | BLACK                      | CE 319252                           |  |
| <b>NS5100</b>                   |  |                            |                                     |  |
|                                 | Ribbon<br>Ribbon<br>Ribbon High quality              | GREEN<br>RED<br>BLACK      | ZE 490170<br>YK 629672<br>CE 319550 |  |
| <b>PIX10/PIX15</b>              |  |                            |                                     |  |
|                                 | Ribbon   | BLACK                      | CE 315153                           |  |
| <b>PIX21</b>                    |  |                            |                                     |  |
|                                 | Ribbon   | BLACK                      | CE 315153                           |  |
| <b>PIX200</b>                   |  |                            |                                     |  |
|                                 | Ribbon   | BLACK                      | CE 315153                           |  |
| <b>PIX3000X</b>                 |  |                            |                                     |  |
|                                 | Ribbon<br>Ribbon<br>Ribbon                           | BLACK<br>RED<br>GREEN      | CE 315153<br>YK 629672<br>ZE 490170 |  |
| <b>PIX3000</b>                  |  |                            |                                     |  |
|                                 | Ribbon   | BLACK                      | CE 315153                           |  |